



Prior to fitting, lubricate o-rings and seals with just enough silicon (grease or spray) to give a glossy finish.

