



Prior to fitting, lubricate seals and o-rings with just enough silicone (grease or spray) to give them a glossy finish.

Honda RVF400 NC35

